



# FlexiPAWS CLOUD

Please use a regular inflatable pump or an air compressor for inflation of the FlexiPAWS Cloud. In winter season, please wait to begin the inflation process until the product has reached room temperature (65-75F or 65 or 18-23C).

There is no difference between the colors of the FlexiPAWS Cloud. It is the same product: ie size, material and texture.

Please ensure adequate inflation when using the Cloud. The bottom should be slightly curved and should not be flat when placed on the floor. If flat on the bottom, it means the product does not have enough air and the desired conditioning is minimized.

Important to note: The difficulty of balancing on the product increases the more the bottom is curved.

We have chosen two different textures to have the possibility to exercise with the level of difficulty you desire. As extra support, we recommend the Flexiness® SensiMats.

For cleaning, use a mild solution of warm water and dishwashing soap. Do not use unconcentrated cleaning products or bleach directly on your Clouds. Do not leave your products in the direct sunlight when not product is not in use.

The Clouds are not toys. Please do not leave your dogs unattended (or your children, for that matter) with the Clouds.

Have fun with your new FlexiPAWS Cloud.

Safety Video available on FitPAWS YouTube Channel.

**[www.youtube.com/fitpaws](http://www.youtube.com/fitpaws)**

Direct link to Cloud Safety Video: [https://youtu.be/k\\_m3oQjasfg](https://youtu.be/k_m3oQjasfg)

**For more information contact FitPAWS at: [info@fitpawsusa.com](mailto:info@fitpawsusa.com)**