

Hurdle Set

Congratulations on the purchase of your new FitPaws Hurdle Set. The FitPaws Hurdle Set is an incredible value for the backyard agility enthusiast, traveling animal rehab practitioner or professional dog trainer. Completely adjustable and portable dog agility cone and hurdle set includes four 40" jumping bars, eight highly-visible orange hurdle cones, eight height-adjustment attachments and a black nylon carrying bag.

- USE INDOORS OR OUTDOORS
- HEIGHT OF JUMPING BAR ADJUSTS IN 2" INCREMENTS FROM 2"-30"
- PERFECT FOR EASY REHABILITATION OR MORE CHALLENGING AGILITY TRAINING
- LIGHTWEIGHT FOR ON-THE-GO PORTABILITY
- SOME ASSEMBLY REQUIRED



FITPAWS HURDLE SET SAFETY, CARE AND USE INSTRUCTIONS

- Do not use your FitPaws Hurdle Set until you have read this instruction/information sheet in full.
- User assumes the risk when using this product. FitPaws shall not be liable for any damages that result from the use of this product.
- Use common sense. Never over-exercise or over-tire your dog when working on canine conditioning equipment. There are inherent risks with any exercise program. Consult your canine health care professional before beginning this or any exercise program.
- Provide enough unobstructed space when using the FitPaws Hurdle Set and clear any furniture or other objects in the area that could cause injury.
- This product is not a toy and should only be used by dogs with appropriate adult supervision.
- Keep this instruction sheet for future use.

GETTING STARTED The FitPaws Hurdle Set

Requires some assembly. Once you decide what level of height you wish to start your dog at (2"-30"), you can attach the height-adjustment attachments to the cones and set the bar. Be sure and provide enough space between the jumps so that your dog has ample room to run between jumps.



Highest adjustment: 30" height.

For this height, you will need to attach the back hook at the bottom of the black attachment into the top hole of the cone.

Then slide the yellow tab down into the slot at the top of the cone until it is holding the attachment firmly in place.



Lowest adjustment: 2" Height

For this height, first slide the yellow tab to the 3rd slot from the bottom.

Then place the yellow tab into the middle hole of the cone. Pull down firmly on the black attachment until the top hook slides down into the top slot of the cone.

LIMITED WARRANTY

Please see updated FitPaws warranty info and exercises on-line at fitpaws.com/info